

Solenoid Valve - Model L36 - 3/8"-1" 2/2 Normally Closed



- Specification & Dimensions: **Pages 2-3**
- Installation & Maintenance Procedures: **Page 4**
- Wiring Details IP67 Housing Solenoid Coil: **Page 5**
- Solenoid Coil Replacement IP67 Housing: **Pages 6-8**

Solenoid Valve - Normally Closed - Direct Acting

Benefits & Features

- Installation in any position
- Suitable for gaseous and liquid media
- Brass or 316 Stainless Steel (1/2" & 3/4" only)
- Low pressure applications
- Ex-d IIC -60°C to +60°C ambient versions
- ATEX, EAC Ex (CU TR 012) and IECEx, Ex-d approved
- High pressure model option (/AP)

Specification

Configuration	Pilot Piston
Port Sizes	3/8" to 1"
Orifice	see data table below
Body	Brass or 316 stainless steel
Media	Air, gases, liquids etc. Subject to material compatibility
Pressure ranges	See individual data tables below
Seals	see order codes table



Technical Data

Standard Model

							Port Size BSP or NPT	Orifice mm	Min. /Max. Operating Differential Pressures. BAR.			KV Flow Factor L/min.
									Min.	Maximum		
										AC	DC	
L36	A	12	B	C	D	E	¾"	12.7	0	10	10	35
L36		12	F/G				½"	12.7	0	10	10	40
L36		18	H/I				¾"	18	0	6	6	87
L36		25	L/M				1"	25	0	3	3	140


High Pressure Model /AP

							Port Size BSP or NPT	Orifice mm	Min . /Max. Operating Differential Pressures. BAR.			KV Flow Factor L/min.	
									Min.	Maximum			
										AC	DC		
L36	A	12	B E /T	C	D	E	⅜"	12.7	0	10	10	35	
L36		12	F/G				½"	12.7	0	10	10	40	
L36		18	H/I				¾"	18	0	10	10	87	
L36		25	L/M				1"	25	0	6	6	140	
												/AP6	24VDC 15W T5

/AP6 24VDC 15W T5

Solenoid Valve - Normally Closed - Direct Acting

Weights & Dimensions



Port Size	Weight Kg	Dimensions mm					
		Brass Body	Stainless Steel Body	B	C	D	E
		A	A				
3/8"	1.1	64	/	14	115	128	45
1/2"	1.1	64	66	14	115	128	45
3/4"	1.4	82	88	17	119	136	55
1"	1.9	100	/	20	135	155	70

Order Codes

A	Body	B	Port			C	Seals (fluid temp. min / max)	D	Protection	E	Options
T	Brass	E	3/8" BSP	T	3/8" NPT	0	NBR (-10°C to + 70°C)	P	IP65 Safe Area	/AP	High pressure model
I	316 Stainless steel*	F	1/2" BSP	G	1/2" NPT	1	VITON (-10°C to + 90°C)	S	IP67 Safe Area	/SG	Degreased for oxygen
*1/2" and 3/4" only		H	3/4" BSP	I	3/4" NPT	3	RULON (-10°C to + 120°C)	B	II 1/2 GD Ex-d IIB T6 (-20 to +40°C)		
		L	1" BSP	M	1" NPT	6	EPDM (-10°C to + 90°C)	C	II 1/2 GD Ex-d IIC T6 (-20 to +40°C)		
					7	HNBR (-45°C to + 90°C)	/LT	II 1/2 GD Ex-d IIC T6 (-60 to +60°C)			
							H	Ex-d c IIB IP67 IECEX			
							T	Ex-d c IIC IP67 IECEX			
							R	Ex-d IIC EAC Ex			

Solenoid Valve Installation & Maintenance

Installation Procedures & Methods

Section 1: How to install Solenoid Valves

Solenoid Valves can normally be installed and operate in any orientation. However, certain models are designed to operate in horizontal installations. Please contact Red Dragon for further information.

Installation Procedure:

Check that the Solenoid Valve is the correct product ordered for the application:

- Isolate the site electrical power supply
- Isolate the site media supply (dependant on the application)...air, water, steam etc. Leave until cool/safe.
- Insert the valve onto the pipe, ensuring that the flow direction is observed.....IN for incoming media, or an arrow stamped on the valve body.
- Ensure that the pipe connections are free from burrs or loose pipe thread tape
- Tighten all pipe joints
- Connect electrical power supply via DIN electrical socket connector, as detailed in section 1
- Ensure that DIN connector is properly connected to solenoid coil and the gasket is installed correctly
- Apply media pressure and check for leaks

Section 2: Maintenance Procedure for Solenoid Valves - IP65 Safe Area

In the unlikely event of a valve malfunction, or routine maintenance, follow these instructions:

- Isolate the site electrical power supply
- Isolate the site media supply (dependant on the application)...air, water, steam etc.
- Remove the solenoid coil by unscrewing the coil retention nut anti-clockwise
- Remove the coil tube stem by unscrewing anti-clockwise
- Carefully remove the plunger assembly (inside the coil stem)
- Check the plunger assembly for damage or worn seals
- Check the face inside the coil stem for foreign particles that could prevent correct operation
- For Pilot Diaphragm Solenoid Valves: remove the top cover housing and check the diaphragm for damage and blocked transfer port.
- Re-assemble the valve in reverse order, ensuring that all parts are cleaned and assembled correctly

Section 3: Maintenance Procedure for Solenoid Valves - IP67 Safe Area & EExd with Housing

In the unlikely event of a valve malfunction, or routine maintenance, follow these instructions:


- Isolate the site electrical power supply
- Isolate the site media supply (dependant on the application)...air, water, steam etc.
- Remove the solenoid coil by unscrewing the coil retention nut anti-clockwise
- Remove the coil tube stem by unscrewing anti-clockwise
- Carefully remove the plunger assembly (inside the coil stem)
- Check the plunger assembly for damage or worn seals
- Check the face inside the coil stem for foreign particles that could prevent correct operation
- For Pilot Diaphragm Solenoid Valves: remove the top cover housing and check the diaphragm for damage and blocked transfer port.
- Re-assemble the valve in reverse order, ensuring that all parts are cleaned and assembled correctly

Electrical Wiring - IP67 Housing


Installation Procedures & Methods




Attention: For safety purposes, always ensure that the power supply is disconnected. After de-energising, allow 15 minutes before continuing the following procedures




A



B





C



Pipe fittings used for cable entry (Cable, duct, conduit etc) are NOT supplied by the manufacturer. Installation engineers should ensure that the use of fittings are of the correct diameter and suitable to secure the tightness of the cable used. Where site conditions indicate, cable duct, conduit etc. must be ATEX approved, for a protection degree equal or greater than the protection degree indicated on the rating plate. The thread type is indicated on the housing: M20*1.5mm, 1/2"NPT or 1/2"GK

D



Earth Tag. Can be customised with Tag number, part number etc.



Solenoid Valve Maintenance - IP67 Housing

Solenoid Coil Removal - Operations 1-2

Tools Required



1	Solenoid housing security clip extraction tool (KM/3062)
2	Flat screwdriver (max. 3x1)
3	Special fixed core wrench (KM/2621)
4	Fixed core wrench lever pin 8mm
5	Setscrew wrench no.2
6	19mm spanner




Ensure that the power supply is switched off before commencing the following procedures

Operation 1



Loosen the security dowel using the setscrew wrench 5

Operation 2



Unscrew the solenoid Housing threaded cap, By turning anti-clockwise






Solenoid Valve Maintenance - IP67 Housing

Solenoid Coil Removal - Operations 3-5

Operation 3



Insert the clip extraction tool in the solenoid housing security clip. Gently pull the clip away from the housing until it is extracted.



Operation 4

Loosen the terminal board screws and pull out the two power supply Wires (A)



It is not necessary to unscrew the internal earth connecting wire.



Operation 5 (if fitted)

Depending on the model, loosen the hexagonal nut with a 19mm spanner, turning anti-clockwise (A)

Once loose, unscrew the nut by Hand (B)







Solenoid Valve Maintenance - IP67 Housing


Solenoid Coil Removal - Operations 6-8

Operation 6



If operation 5 was necessary, carefully extract the O ring from the solenoid coil housing

Operation 7



Pull up the solenoid housing until the solenoid coil is clear of the pilot assembly tube C.

Operation 8



Extract the solenoid coil from the housing, by twisting it gently leading with the top edge.